Cattle Drafter Set Up

1.Connect the Coms Cable from the Drafter Control Box to the Top port of the Indicator as shown below

4.Press **'SELECT'** Button

2.Rotate Indicator Control Dial on the indicator to **'S'** setting

3.Push Down Arrow until Disp

'5. COMMUNICATIONS'

5. Set **Port 1** to **Drafter** by pushing the **Change** button to scroll through the options.
6. Press the **Ok** button
7. Scroll back up through the options to **1. Draft Menu** and press the **Select** button
8. If the top line of the bottom screen does not read **"Three Way Drafting"** then scroll though the options by pressing the **mode** button

Now set up the weights and gate options. Note that for the cattle drafter, 2 is left, _ is no draft go straight ahead and 1 is right.

For example, if you wish to draft animals above 200kg to the right, between 200 and 150kg straight ahead and below 150kg to the left then set the gates up to read

<u>Three Way Drafting</u>

H GATES 1

Upper limit 150kg

C GATES

Lower Limit 200kg

L GATES 2

NZ 0800 80 90 98

AUS 1800 124 034